

Alpha Wire Part Number Ordering Guide

Step 1: Start with the base part number (sometimes classified as the item number).

Ex: 5002C, 9008A, V16001, 1550, FIT-221-1/8

Step 2: Then choose jacket color, use the abbreviation

Color Putup	Color (jacket)
BK	Black
BL	Blue
BR	Brown
GR	Green
GY	Green/Yellow
NA	Natural
OR	Orange
RD	Red
SL	Slate
VI	Violet

Step 3: Choose put up code, use the abbreviation for the part number

Put Up Code	Description
001	1000 FT
002	500 FT
005	100 FT
021	Box 1000 FT
066	14X6 Inches

Step 4: Alpha Wire Part Number Examples

Item Number: 5002C

Item Color: Gray/Slate

Item Put Up: 1000 Ft

Part Number System: 5002C SL001

Item Number: 3070

Item Color: Black

Item Put Up: 100 Ft

Part Number System: 3070 BK005

Conductor Color Coding

The Put Up information listed below is specifically regarding Alpha Wire's Hook Up Wire and not related to any other product line.

Hook-Up Wire

Chart Z1	
No.	Color
1	White
2	Black
3	Red
4	Green
5	Yellow
6	Blue
7	Brown
8	Orange
9	Slate
10	Violet
11	White/Black
12	White/Red
13	White/Green
14	White/Yellow
15	White/Blue
16	White/Brown
17	White/Orange
18	White/Slate
19	White/Violet
28	Green/Yellow
29	Yellow/Green
30	Pink

Chart Z2	
No.	Colors
0	Black
1	Brown
2	Red
3	Orange
4	Yellow
5	Green
6	Blue
7	Violet
8	Slate
9	White
45	Yellow/Green
54	Green/Yellow
90	White/Black
91	White/Brown
92	White/Red
93	White/Orange
94	White/Yellow
95	White/Green
96	White/Blue
97	White/Violet
98	White/Slate
P	Pink
T	Tan
X	Clear

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Alpha Wire:

[777B SL076](#) [781 BK078](#) [537 BK078](#) [683/2 BK038](#) [640 BK038](#) [654 BK038](#) [780B SL076](#) [722/2R BK032](#) [760/4 BK038](#) [615 BK078](#) [6410 SL001](#) [PRM1004 WH005](#) [6435 SL001](#) [6441 SL002](#) [6444 SL001](#) [M4243 BK001](#) [6436 SL002](#) [M4243 BK002](#) [6447 SL001](#) [6439 SL001](#) [6389 SL001](#) [6443 SL001](#) [6410 SL002](#) [505B BK076](#) [6440 SL001](#) [1937 BK003](#) [6389 SL005](#) [6445 SL002](#) [6301 SL001](#) [6437 SL001](#) [6448 SL001](#) [6448 SL002](#) [9105 BK002](#) [6411 SL001](#) [6445 SL001](#) [5762S BR005](#) [523 BK078](#) [M9020012 BK001](#) [6444 SL002](#) [6301 SL002](#) [M213302 SL002](#) [6438 SL002](#) [6437 SL002](#) [M4207 BK002](#) [6304 SL002](#) [6442 SL001](#) [6442 SL002](#) [6434 SL001](#) [6446 SL001](#) [470 BK078](#) [6436 SL001](#) [6446 SL002](#) [6411 SL002](#) [6443 SL002](#) [M4207 BK001](#) [M4207 BK005](#) [6389 SL002](#) [6435 SL002](#) [5776 BR005](#) [6304 SL005](#) [6447 SL002](#) [6440 SL002](#) [6438 SL001](#) [6439 SL002](#) [551 BK078](#) [506 BK078](#) [M4243 BK005](#) [6304 SL001](#) [5640B2201 NC001](#) [6441 SL001](#) [3590/26 SL005](#) [3590/16 SL005](#) [M243142 WH001](#) [M39132 SL005](#)