

When ordering hook up wire, start with the base part number. Then use the following abbreviations for the desired color:

| | |
|----|--------------|
| BK | Black |
| BL | Blue |
| BR | Brown |
| GR | Green |
| GY | Green/Yellow |
| OR | Orange |
| PK | Pink |
| RD | Red |
| SL | Slate |
| VI | Violet |
| WH | White |
| YG | Yellow/Green |
| YL | Yellow |

Finally, use the following put up code for the desired put up:

| | |
|-----|--------|
| 005 | 100FT |
| 001 | 1000FT |
| 013 | 5000FT |

For example, if you were ordering 1000ft of part number 3070 in black, the part number would look like 3070 BK001.