

[Amphenol Worldwide](#) [Amphenol RF Employment](#) [Engineering Focus](#) [Quality Focus](#) [Weather and Directions](#)
[Locate A Distributor](#) [Check Distributor Inventory](#)
[Frequency Range Chart](#) [Glossary](#) [Technical Questions](#) [VSWR Calculator](#) [VSWR Chart](#)
[Customer Drawings](#) [Assembly Instructions](#) [Catalog](#)
[Product Overview](#) [Product Search](#) [Cross Reference](#) [QPL Products](#) [Markets Served](#) [Product Literature](#)
[Newsletter](#)
[Customer Extranet](#) [Salesperson Extranet](#) [Vendor Extranet](#) [Employee Extranet](#) [Internal Employee Extranet](#)
[Amphenol RF Manufacturers Rep.](#)

Product Search

[1.0/2.3](#)
[1.6/5.6](#)
[AFI](#)
[AMC](#)
[BNC / RP-BNC](#)
[C](#)
[FAKRA SMB](#)
[FME](#)
[HD BNC](#)
[HN](#)
[MCX](#)
[Mini BNC](#)
[Mini UHF](#)
[Mini 75 Ω SMB](#)
[MMCX](#)
[Precision \(APC\)](#)
[QMA](#)
[SC](#)
[SMA / RP-SMA](#)
[SMB](#)
[SMC](#)
[SMP](#)
[SSMB](#)
[TNC / RP-TNC](#)
[Triax](#)
[True 75 Ω BNC](#)
[Twin BNC](#)
[Twinax](#)
[Type F](#)
[Type G](#)
[Type N](#)
[UHF](#)
[Reverse Polarity](#)
[Adapters](#)
[Tools](#)
[Accessories](#)
[Product Search](#)
[src="/images/dottedline.gif" >](#)
[Inventory Search](#)

QPL Products

Our list of QPL products includes rf connectors and adapters qualified under the government performance specifications MIL-PRF-39012 and MIL-PRF-55339. Following our QPL part numbers are other UG numbers listed for reference.

Looking for something not on this list? Send us an email at military@amphenolrf.com and we'll be glad to help you out.

	Amphenol Part Number	QPL Number	Description
Mini BNC	031-3301	M39012/16-0101	BNC Plug UG Clamp for RG 56, 141, 142, 223
Mini UHF	031-3302	M39012/16-0102	BNC Plug UG Clamp for RG 62C, 140B, 210
Mini 75 Ω SMB	031-3376	M39012/21-0002	BNC Bulkhead Receptacle Front Mount
MMCX	031-4237	M39012/24-0001	BNC Rear Mount Hermetic Receptacle
Precision (APC)	031-4238	M39012/24-0002	BNC Front Mount Hermetic Receptacle
QMA	031-4320	M39012/16-0013	BNC Plug for RG 58, 141, 303
SC	031-4321	M39012/16-0015	BNC Plug for RG 59, 62, 140, 210
SMA / RP-SMA	031-4326	M39012/16-0014	BNC Plug for RG 55, 142, 223
SMB	031-4327	M39012/17-0013	BNC Jack for RG 58, 141
SMC	031-4328	M39012/17-0015	BNC Jack for RG 59, 62, 140, 210
SMP	031-4427	M39012/16-0503	BNC Plug for RG 142, 400
SSMB	031-4452	M39012/26-0503	TNC Plug for RG 142B, 400
TNC / RP-TNC	082-332	M39012/01B0008	Quick Crimp Type N Plug for RG 9, 9A, 214
Triax	082-340	M39012/01B0007	Quick Crimp Type N Plug for RG 8, 8A, 213
True 75 Ω BNC	082-368	M39012/04-0002	Type N 4-Hole Flange Panel Jack
Twin BNC	082-3106	M39012/25-0011	
Twinax	082-4336	M39012-05-0005	
Type F	082-4352	M39012/01-0005	Type N Pin Contact for RG 213, 214, 225
Type G	082-4425	M39012/01-0501	Type N Pin Contact for RG 214, 225, 393
Type N	082-4426	M39012/01-0502	Type N Pin Contact for RG 8, 213
UHF	082-4427	M39012/01-0503	Type N Pin Contact for RG 400, 142B
Reverse Polarity	082-4438	M39012/03-0503	Type N Bulkhead Jack for RG 214 Cable
Adapters	082-4440	M39012/05-0501	Type N Right Angle Plug for RG 9, 214, 225, 393
Tools	082-4442	M39012/05-0503	Type N Right Angle Plug for RG 142B, 400
Accessories	082-4450	M39012/35-0501	SC Plug for RG 9, 214, 225, 393
Product Search	082-4451	M39012/35-0503	SC Plug for RG 142B, 400
Inventory Search	082-4454	M39012/40-0501	
	082-4455	M39012/40-0503	
	082-4460	M39012/38-0501	SC Flange-Mounted Jack for RG 214, 223, 393
	082-4474	M39012/39-0501	SC Right Angle Plug for RG 9, 214, 225, 393
	082-5552	M55339/04-00030	
	082-5558	M55339/20-00201	BNC Socket to Type N Pin Adapter
	901-101-11	M39012/55B4022	SMA Crimp Plug for RG 142, 223
	901-101-15	M39012/55-4502	SMA RG142B,400 Plug
	901-103-11	M39012/55-4009	SMA Clamp Plug for RG 55, 58, 142, 223

901-116	M39012/61-4001	
901-125-11SF	M55339/02-30001	SMA Right Angle Adapter
901-128-11	M39012/55-4007	SMA Clamp Plug for RG 174, 188, 316
901-148-15	M39012/56-4502	SMA Right Angle Plug for RG 142, 400
901-155-11	M39012/55B4019	
901-155-12	M39012/55B4012	SMA PCB Jack
901-155-16	M39012/55-4026	SMA Straight Crimp Plug for RG 174, 316
901-255-11	M39012/59-4006	
901-256-11	M39012/59-4007	
901-291-15	M39012/59-4502	
901-368-12	M39012/56-4007	SMA Right Angle Plug for RG 174, 188, 316
227-1221-3	M22520/5-03	Crimp Tool
227-1221-9	M22520/5-09	Crimp Tool
227-1221-11	M22520/5-11	Crimp Tool
227-1221-15	M22520/5-15	Crimp Tool
227-1221-23	M22520/5-23	Crimp Tool
227-1221-29	M22520/5-29	Crimp Tool
227-1221-37	M22520/5-37	Crimp Tool
227-1221-57	M22520/5-57	Crimp Tool
227-1221-59	M22520/5-59	Crimp Tool
227-1221-11	M22520/5-11	Crimp Tool
227-1221-13	M22520/5-13	Crimp Tool
227-1221-09	M22520/5-09	Crimp Tool
227-1221-32	M22520/5-09	Crimp Tool
227-1221-25	M22520/5-57	Crimp Tool
227-1221-57	M22520/5-57	Crimp Tool
227-1221-11	M22520/5-11	Crimp Tool
227-1221-13	M22520/5-13	Crimp Tool
227-1221-57	M22520/5-57	Crimp Tool
227-1221-59	M22520/5-59	Crimp Tool
227-1221-09	M22520/5-09	Crimp Tool
227-1221-13	M22520/5-13	Crimp Tool
227-1221-32	M22520/5-13	Crimp Tool
031-6	CW-123/U	BNC 50 Ohm Male Cap Chain
031-17	CW-159/U	BNC 50 Ohm Male Shorting Cap Chain
33-7217-1	CW-767/U	Male cap & chain
083-1AP	MX-103/U	Angle adapter(p/j)
103-301	MX-554/U	Cable trimmer
082-106	MX-1143/U	Male cap & chain
000-1025	MX-1684/U	Terminator
083-1SP	PL-259	Plug
083-822	PL-259	Plug
083-756	PL-259A	Plug
083-1R	SO-239	Panel receptacle
083-798	SO-239A	Panel receptacle
082-201	UG-20C/U	Jack
082-61	UG-21B/U	Plug
082-96	UG-21C/U	Plug
082-3202	UG-21E/U	Plug
082-202	UG-21D/U	Plug
082-62	UG-22B/U	Panel jack
082-94	UG-23C/U	Jack
082-209	UG-23D/U	Jack
082-3209	UG-23E/U	Jack
082-64	UG-27A/U	Angle adapter(j/p)
082-98	UG-27B/U	Angle adapter(j/p)
082-213	UG-27C/U	Angle adapter(p/j)
082-99	UG-28A/U	Tee adapter(j/j/j)
082-65	UG-29A/U	Adapter(j/j)
082-101	UG-29B/U	Adapter(j/j)
082-66	UG-30/U	Bulkhead adapter(j/j)
082-201	UG-30C/U	Bulkhead adapter(j/j)
000-91100	UG-30D/U	Bulkhead adapter(j/j)
082-100	UG-57B/U	Adapter(p/p)

082-24	UG-58/U	Panel receptacle
082-97	UG-58A/U	Panel receptacle
082-38	UG-59A/U	Plug
082-804	UG-59B/U	Plug
000-14000	UG-83/U	Adapter(n jack/uhf plug)
000-34125	UG-83B/U	Adapter(n jack/uhf plug)
031-2"	UG-88/U	Plug
031-18	UG-88B/U	Plug
031-202	UG-88C/U	Plug
031-202	UG-88E/U	Plug
031-5	UG-89/U	Jack
000-7200	UG-91A/U	Plug
083-1H	UG-106/U	Hood,4-hole flange mt. For rg-8
082-102	UG-107B/U	Tee adapter(j/p/j)
083-750	UG-111/U	Plug
000-4400	UG-146/U	Adapter(n plug/uhfjack)
082-59	UG-154/U	Plug
082-67	UG-160A/U	Bulkhead jack
082-104	UG-167A/U	Plug
083-185	UG-175/U	Reducing adapter rg-58
083-168	UG-176/U	Reducing adapter rg-59
083-765	UG-177/U	Hood,4-hole flange mt. On rg-58
4000-500	UG-185/U	Panel receptacle
031-216	UG-201A/U	Adapter(bnc jack n/plug)
082-91	UG-212A/U	Angle adapter(j/p)
000-2900	UG-255/U	Adapter(bnc plug/uhf jack)
031-12	UG-260/U	Plug
031-21	UG-260A/U	Plug
031-212	UG-260B/U	Plug
031-3212	UG-260D/U	Plug
031-15	UG-261/U	Jack
031-28	UG-273/U	Adapter(bnc jack/uhf plug)
031-8	UG-274/U	Tee adapter(j/p/j)
031-208	UG-274A/U	Tee adapter(j/p/j)
031-2208	UG-274B/U	Tee adapter(j/p/j)
031-203	UG-290AU	Panel receptacle
031-1	UG-291/U	Panel jack
31-207	UG-291B/U	Panel jack
031-2201	UG-291C/U	Panel jack
031-9	UG-306/U	Angle adapter(j/p)
031-209	UG-306A/U	Angle adapter(j/p)
031-2209	UG-306B/U	Angle adapter(j/p)
031-217	UG-349A/U	Adapter(bnc plug/n jack)
082-80	UG-352/U	Panel jack
0083-1F	UG-363/U	Bulkhead adapter (j/j)
000-47000	UG-414/U	Panel adapter(j/j)
000-47025	UG-414A/U	Panel adapter(j/j)
000-32225	UG-421B/U	Plug
000-6225	UG-422/U	Panel receptacle
031-218	UG-491A/U	Adapter(p/p)
031-220H	UG-492A/U	Herm. Bulkhead adapter (j/j)
031-3220	UG-492D/U	Herm. Bulkhead adapter (j/j)
082-92	UG-496/U	Panel receptacle 4 hole,sqr flange
000-5675	UG-535/U	Angle panel receptacle
000-34000	UG-536/U	Plug
000-34025	UG-536B/U	Plug
000-35275	UG-556B/U	Bulkhead jack
082-805	UG-560/U	Panel receptacle 4 hole,sqr flange
082-508	UG-564/U	Adapter c jack/n plug
082-504	UG-568/U	Panel receptacle
082-530	UG-573A/U	Plug
000-15425	UG-594A/U	Angle plug
000-34500	UG-603/U	Plug
000-34525	UG-603A/U	Plug

000-5575	UG-625/U	Bulkhead receptacle
031-236	UG-625B/U	Bulkhead receptacle
082-532	UG-628A/U	Plug
082-515	UG-634/U	Bulkhead receptacle
083-1AP	UG-646/U	Angle adapter(j/p)
031-102	UG-657/U	Bulkhead receptacle
031-239	UG-657A/U	Bulkhead receptacle
031-206	UG-909/U	Bulkhead jack
31-207	UG-910/U	Bulkhead jack
031-238	UG-912/U	Bulkhead receptacle
031-204	UG-913/U	Angle plug
031-219	UG-914/U	Adapter(j/j)
000-27000	UG-931/U	Panel receptacle
000-28000	UG-932/U	Plug
000-27975	UG-932A/U	Plug
082-3204	UG-941B/U	Plug
000-6775	UG-959/U	Plug
000-28175	UG-961A/U	Panel jack
000-8975	UG-997A/U	Panel receptacle
000-27075	UG-1016A/U	Jack
000-11050	UG-1019/U	Bulkhead adapter (j/j)
000-84975	UG-1033/U	Plug
000-5225	UG-1034/U	Adapter(bnc plug/n plug)
000-36000	UG-1052/U	Panel jack
031-221	UG-1094/U	Bulkhead receptacle
031-2221	UG-1094A/U	Bulkhead receptacle
000-36250	UG-1095A/U	Panel jack
031-222	UG-1098/U	Angle bulkhead receptacle
082-312	UG-1185/U	Plug
082-3312	UG-1185A/U	Plug
082-313	UG-1186/U	Jack

 [back to top](#)