







$V_{RRM} = V_{DRM}$ (V)	25 30 50 100 200 300 400 500 600 700 800											Case
	I_T (RMS) (A)											
metal packages boîtiers métal												
0,5	2N 877... $I_{GT} = 0,2 \text{ mA}$										 TO 18  TO 39	
0,5	TE 205... $I_{GT} = 0,5 \text{ mA}$											
1,6	2N 2322... $I_{GT} = 0,2 \text{ mA}$											
plastic packages boîtiers plastiques												
0,8	BRY 55... $I_{GT} = 0,2 \text{ mA}$										 F 139B  TO 92	
0,8	BRY 55M... asymmetrical series $I_{GT} = 0,2 \text{ mA}$											
1	2N 6681... $I_{GT} = 0,2 \text{ mA}$											
1,6	TL 106... $I_{GT} = 0,2 \text{ mA}$										 TL  TO 220 AB	
1,6	TL 107... $I_{GT} = 0,5 \text{ mA}$											
4	TLS 106... $I_{GT} = 0,2 \text{ mA}$											
4	TLS 107... $I_{GT} = 0,5 \text{ mA}$											
4	TYS 406 ... $I_{GT} = 0,2 \text{ mA}$											
4	TYS 407 ... $I_{GT} = 0,5 \text{ mA}$											
6	TYS 606 ... $I_{GT} = 0,2 \text{ mA}$											
6	TYS 607 ... $I_{GT} = 0,5 \text{ mA}$											
8	TYS 806 ... $I_{GT} = 0,2 \text{ mA}$											
8	TYS 807 ... $I_{GT} = 0,5 \text{ mA}$											
10	TYS 1006 ... $I_{GT} = 0,2 \text{ mA}$											
10	TYS 1007 ... $I_{GT} = 0,5 \text{ mA}$											